




EZ



A removable plastic sleeve for forming quick, accurate, clean post holes in concrete.



**Set before or immediately after concrete is poured.
Leave EZ Sleeve in place & remove before railing installation.
It forms a tapered hole.**

Ideal for railings, fences or other posts. Easy to use. Lightweight, yet sturdy. Convenient. Precise field measurements. Sealed tapered tube keeps out debris and water.


EZ SLEEVE

Description:

EZ Sleeve is the ideal way to form quick and clean post holes in concrete for installing railings, fences or other posts.

Features:

- **Easy to use:** Set before or immediately after concrete is poured.
- **Lightweight and sturdy:** The sleeve is constructed of 1/16 inch thick plastic.
- **Precise field measurements:** Use tab for field measuring and removal of sleeve.
- **Clean:** Sealed tapered tube with snap-on base keeps out debris and water.
- **Convenient:** Creates tapered hole with extra space to plumb post.




NOTE I: Plastic feet for fastening to form work


EZ SLEEVE

Suggested rail post installation:

MODEL	DIM. (IN.)				POST SIZE OF RAILING OR FENCE
	T	B	H	C	
3006	3"	3 1/2"	6"	4 3/4"	Up to 2" Pipe (2 3/8" OD) Up to 2" Square Post
4012	4"	5"	12"	7"	Up to 3" Pipe (3 1/2" OD) Up to 2 1/2" Square Post




How to use EZ SLEEVE:




EITHER...
Attach to concrete formwork and pour concrete.






OR...
Press into wet concrete.



Pull tab, using a pair of pliers, just before installing posts. Do Not pull out EZ SLEEVE until ready for installation. You can use it to verify field measurements and to keep out debris and water which can freeze and crack concrete.



After concrete has set, field verify post spacing by measuring centerline distance of EZ SLEEVE:




Fill with grout

Note: Color is safety orange to safeguard against tripping. Public access to work area should be prevented.

NOTE: Do not break seal on top of sleeve until ready for rail installation

Avoid rust caused by steel sleeves, railings not properly coated, or posts not properly grouted.



SECTION 05720 PLASTIC POST HOLE FORM

PART 1 – GENERAL

1.1 SUMMARY

A. Section includes: Plastic form to create holes in concrete for installation of posts and other grouted items.

1.2 SUBMITTALS

A. Provide product data and installation instructions.

PART 2 – PRODUCTS

2.1 ACCEPTABLE MANUFACTURER

A. Auciello Iron Works, Inc., 560 Main Street, Hudson, Massachusetts 01749:
Phone: 978-568-8382

2.2 POST HOLE FORM

- A. Type: Orange polyethylene, 1/16 inch thick, round form with closed top and snap-on base. Embedded in concrete to create tapered hole, Model [_____]. EZ Sleeve is manufactured by Auciello Iron Works, Inc.
- B. Height: [6 inches for 2-3/8 inches maximum diameter posts.] ***OR*** [12 inches height for 3-1/2 inches maximum diameter posts.]
- C. Description: Top prevents debris entering hole. Top tab indicates hole center. Helical groove inside allows easy removal. Pulling top tab separates form along groove. Snap-on flanged base has holes for anchoring to reinforcement or formwork.

PART 3 – EXECUTION

3.1 INSTALLATION

- A. Installation prior to pouring concrete: Anchor form with staples, nails, or wire through base flanges or top tab. ***OR*** Installation after concrete placement: Immediately after placing concrete, press post hole form into concrete.
- B. Accurately locate post hole forms. Use top tabs to determine spacing and alignment. Ensure forms are vertical and top is flush with concrete surface.
- C. When concrete has set, grip top tab with pliers and pull form from hole.
- D. Place posts in holes, brace or wedge to ensure components are vertical and rigid, and fill hole with grout. Maintain bracing until grout sets.